

F&F Filipowski sp. j. Konstantynowska 79/81 95-200 Pabianice phone/fax: (+48 42) 215 23 83 / 227 09 71 POLAND http://www.fif.com.pl e-mail: biuro@fif.com.pl

MICROWAVE MOTION SENSOR

DRM-08

WARRANTY. The F&F products are covered by a warranty of the 24 months from the date of purchase. Effective only with proof of purchase. Contact your dealer or directly with us. More information how to make a compliant can be found on the website: www.ffc.com.pl/reklamacie





To the Law on waste, electro coming from househous free of charge and can give any amount to up to that end point of collection, as well as to store the occasion of the purchase of new equipment (in accordance with the principle of old-for-new, regardless of brand). Electro thrown in the trash or abandoned in nature, pose a threat to the environment and human health.

Purpose

The motion sensor is designed for automatic, scheduled lighting activation if a person or other object appears in places such as corridors, courtyards, approaches and driveways, garages, etc.

The specific of operation allows to use the DRM-08 as a presence sensor. The sensor allows to detect movement through wooden boards, plaster-board panels, glass and plastics.



- 1 -

Settings

Actuation time (TIMF)



Receiver's actuation time can be adjusted between 8 sec for 12 min. Rotate knob to the right increases ON time, 30s rotate left reduces the attached time.

Detection range (SENS)



Radius of the sensor detection can be adjusted in the range from 1 m to 8 m (the parameters for the sensor mounted at a height 1÷6 m). Rotate the knob to the right [+] increases the area of a field of detection, rotate left [-] reduces the area of the field detection.

Sensitivity of light dependant relay (LUX)



Sensitivity of light dependant relay can be adjusted in range from 3Lx to 2000Lx. Rotate the knob to "3" - attached later; rotation to the "sun" sign - attached earlier.

In order to sensor was active throughout the day, set the knob maximally toward the "sun".

Functioning

The DRM sensor emits and receives 5.8 GHz high frequency electromagnetic waves. The sensor detects changes in wave reflection caused by the movement of the object in the detection area. The sensor detects movement of the object to and from the sensor. Movement in the detection area automatically switches on the lighting. From the moment of switching on, continuous movement causes the lighting to stay on permanently. Only lack of movement in the detection area triggers the lighting back-up time. Another movement in the detection area and its disappearance during the count down will start the back-up time from the beginning. The nature of the operation allows the DRM to be used as presence sensor.

After the preset time, the lighting will be switched off automatically. The motion sensor is equipped with a twilight sensor that prevents the controlled lighting from being switched on during the day. The detection status and the readiness to switch on the lights are activated only after dark. Activation time of the sensor can be adjusted by the user through a potentiometer. In addition, it is possible to adjust the detection area in the $\,$ radius range of 1÷8 m (for h=2÷6 m) and to adjust the time of the receiver in the range of 10sec÷12min. The motion sensor can work indoors. The sensor allows to detect movement through wooden boards, plasterboard panels, glass and plastics. Temperature changes do not affect motion detection.

WARNING!

The power of microwave radiation is relatively low and is completely safe for humans and animals. Its value is less than 0.2 mW.

By comparison, microwaves and cell phones radiate about 1000mW of power (100 times harder).

Diagram


- 2 -

- 1. Twist the sensor outer casing off by hand.
- 2. Disconnect the power supply.
- 3. Put the wires through the rubber cable bush in chassis of the sensor.
- 4. Fix the base to the ground.
- 5. Connect according to the diagram.

WARNING!

- **DRM** is inactive for the first 10 seconds after powering up.

 6. Set the detection area, sensitivity of the twilight switch and the switch-
- 7. Assemble the outer casing of the sensor.



- 3 -- 4 -

Wiring diagram




Table of power

| *\}` | = () | ==== | | = |
|--------------|-------------|-------------|---------------|------|
| incandescent | halogen | fluorescent | energy-saving | LED |
| 2000W | 2000W | 300W | 300W | 300W |

Technical data

power supply current load microwave radiation frequency power radiation motion detection detection area detection area detection time of receiver - adjustable switch-on time of receiver - adjustable activation delay power consumption terminal working temperature dimensions mounting protection level 230V AC <10A 5.8GHz <10mW 0.6÷1.5m/sec 360° 1÷8m 3÷2000Ly 1+8m 3+2000Lx 10±3sec+12±1min <1sec 0.9W 1mm² screw terminals -25+50°C Ø115 h=24mm two screws to substrate IP20

- 6 -

- 5 -D161020